

palatov

MOTORSPORT

DUCATI SPORT CLASSIC LICENSE PLATE BRACKET INSTALLATION

1. Remove the original fender assembly, it is held on by four M6 bolts. Disconnect the tail light harness connector.
2. Remove the tail light assembly from the fender. Take off the brake light lens by removing two screws on the sides of the unit and switch the turn signal connectors inside as shown. Reinstall the lens.
3. Assemble the base plate, bracket, and tail light as shown. Use hardware provided with the kit. It may be useful to put pieces of tape over the M6x30 bolt heads to temporarily keep them in place.
4. Install the complete assembly on the bike. This may require a bit of patience with the four bolts. Start the locknuts onto the bolts by hand, then push the whole assembly forward and tighten.
5. Reconnect the harness connector.
6. After the installation is complete, it is strongly recommended that the rear spring preload be set to 1" static sag (stock settings are too soft). For detailed instructions on setting preload see: www.dpcars.net/ps/preload.htm

